

### **MOUNTING SUGGESTIONS:**

# Harley-Davidson® Dyna 1996-2005

Solo and Passenger Seats

Hardware Solo: Passenger seat:

(Included): Fender nut kit 1/4"-20 x 1" buttonhead Allen bolt

Slotted spool washer Mounting bracket 10-32 screws x 2

Small shoulder washer (1996-

2003 only)

Tools needed: Phillips screwdriver

<sup>5</sup>/<sub>32</sub>" Allen wrench

### **Removal of Stock Seat:**

One-piece stock seat:

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock



rear fender screw will be used to attach your new Mustang seat.

- 2. Remove the handstrap if present.
- 3. Slide the seat up and back to disengage the front bracket and remove the seat.

## Installation of Mustang seat:

#### Solo:

- 1. If center mount near front of rear fender is plugged, remove plug and install supplied fender nut.
- 2. Insert nose tab into frame mount under tank.
- 3. Align rear bracket with fender nut. If installing solo alone, secure the bracket to the fender with the stock screw. If installing a passenger seat, secure to the fender with the supplied 1/4"-20 x 1" buttonhead bolt and slotted spool washer.



#### Passenger seat:

- 1. Secure rear bracket to back of baseplate with supplied 10-32 screws. Use the set of holes closest to the rear for Dyna Wide Glide, and the other set of holes for all other Dyna models.
- 2. Remove the stock screw mounting the back of the solo and replace with the supplied  $\frac{1}{4}$ "-20 x 1" buttonhead bolt and slotted spool washer. The slotted washer should sit directly on top of the solo bracket.
- 3. Align slot at front of passenger seat with the slotted spool washer mounted above the solo seat's rear bracket, and slide the seat forward to engage the washer.
- 4. Align rear bracket with fender nut, add washer (1996-2003 only) between fender and bracket, and secure the bracket to the fender with the stock screw.

# Enjoy the comfort and custom look of your new Mustang seat!

