

MOUNTING SUGGESTIONS:

Harley-Davidson[®] Softail 1984-1999

Solo and Passenger Seats

Stock fender screw Black nylon washer

Hardware: Solo: Passenger seat:

Stock fender bolts (or Mustang part 78033)

Side brackets x 2 1/4"-20 x 3/4" bolts x 2 1/4"-20 x 1/2" screw x 2

Tools needed: Phillips screwdriver

These seats will install on the following motorcycles. If your motorcycle is not listed, please contact Mustang for fitment.

- FLST Heritage Softail 1986-1990
- FLSTC Heritage Softail Classic 1988-1999
- FLSTF Fat Boy 1990-1999
- FLSTN Nostalgia 1993-1996
- FXST Softail 1984-1999
- FXSTB Night Train 1999
- FXSTC Softail Classic 1986-1999
- FXSTS Springer 1989-1999
- FXSTSB Bad Boy 1995-1997

Note: Mustang solos/passenger seats will not fit with stock solos/passenger seats.

Removal of stock seat:

One-piece stock seat:

1. Remove the two large Allen mounting bolts from each side of the seat. These will be used to mount the Mustang solo seat.



- 2. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach the Mustang passenger seat.
- 3. Slide the seat up and back to disengage the front bracket and remove the seat.

Installation of Mustang seat:

Solo alone:

- 1. Insert the solo's nose tab into the frame mount behind the tank.
- 2. Align the side brackets with the side frame mounts and re-install the two large Allen bolts. Tighten securely.

Note: The angles of the steel pan may need to be adjusted slightly to fit your specific bike.

Solo and passenger seat:

- 1. Remove the two $\frac{1}{4}$ "-20 x $\frac{1}{2}$ " screws from the bottom of the solo, line up the passenger seat's two front brackets with the holes in the solo and re-install the two screws. Tighten securely.
- 2. Insert the solo's nose tab into the frame mount behind the tank.
- 3. Optional: align the side brackets with the side frame mounts and reinstall the two large Allen bolts. This is not required when installing with the passenger seat attached. These two brackets can be removed from the solo if desired.
- 4. Align the passenger seat's rear bracket with rear mount in the fender, place black nylon washer between the seat bracket and the fender, and secure with stock screw.

Enjoy the comfort and custom look of your new Mustang seat!

