



MOUNTING SUGGESTIONS:

Harley-Davidson® FLT/FLHT 1991-1996 One-piece Seat

Hardware:	Stock 1/4" -20 x 1/2" rear fender screw "Z" bracket with 2 10-32 screws (included)
Tools needed:	Phillips screwdriver

Installation of Mustang Seat:

1. Install the supplied chrome triangle "Z" bracket onto seat baseplate and tighten screws securely.



2. Engage tab on frame of bike into receiver at nose of seat.
3. Firmly push seat forward so the nose meets the chrome dash panel.
4. Align slot in "Z" bracket with threaded hole in Tourpak platform.
5. Secure seat with stock screw.

Note: If installing without the Tourpak, you will need a flat bracket. Contact Mustang to get this bracket.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product.

Refers to part numbers: 75525, 75555, 75565