



MOUNTING SUGGESTIONS:

Harley-Davidson® FXFB Fat Bob 2018 One-piece Seat

Tools needed: Flat-headed screwdriver
 $\frac{5}{8}$ " hex wrench

Removal of Stock Seat:

1. Remove the rear $\frac{1}{4}$ "-20 fender screw with a screwdriver and set it aside. The stock rear fender screw will be used to attach your new Mustang seat.
2. Slide the seat up and back to disengage the front bracket and remove the seat.



3. Remove the handstrap with a $\frac{5}{8}$ " hex wrench.

Installation of Mustang seat:

1. Engage the Mustang solo's front mounting bracket into the frame mount behind the tank.
2. Align the rear bracket with the rear fender nut and secure with the stock screw.



Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product.

Refers to part number: 75709