



MOUNTING SUGGESTIONS:

Kawasaki Vulcan 1600 Classic & Nomad '03-08 - Solo and Passenger Seat

Hardware:	Solo seat: Stock 6mm solo bolt White nylon washer	Passenger seat: Stock 6mm rear bolt White nylon washer
Tools needed:	8mm wrench Metric Allen wrenches	

Removal of Stock Seat:

1. Remove the rear 6mm bolt and set aside. This bolt will be used to mount your new Mustang seat.

2. Slide the rear seat back and up to remove.

3. Remove the passenger handstrap from the motorcycle.

4. Remove the 6mm bolt from the rear of the solo and set aside.

5. Pull solo up and back to remove from the motorcycle.



Installation of Mustang Seat:

1. Center the solo on the motorcycle frame.
2. Push firmly down on the nose of the solo and slide it forward to engage the nose bracket into the receiver under the fuel tank.



3. Align the solo's rear bracket with the fender mount, position a white nylon washer between the bracket and the fender, and secure with the stock bolt.
4. Align the front bracket of the passenger seat with the U-bracket on the fender.

5. Lift the rear of the passenger seat slightly, and slide it forward until the front bracket has engaged the U-bracket and the rear bracket aligns with the rear fender mount.

6. Position a white nylon washer between the rear bracket and the fender hole and secure the seat with the stock 6mm bolt.

Enjoy the comfort and custom look of your new Mustang seat!



View [other motorcycle seats & backrests](#) made by [Mustang](#) on our website.