



MOUNTING SUGGESTIONS:

Yamaha V-Star 650 Classic & Silverado '98-15 - Solo and Passenger Seat

Hardware:	Solo: Stock 8mm bolt White nylon washer	Passenger seat: Stock rear fender screw or nut White nylon washer x 3 Chrome spool washer x 2 6mm x 25mm bolt x 2
Tools needed:	Metric Allen wrenches and sockets	

Removal of Stock Seat:

1. Remove the rear fender screw or nut.



2. Lift rear of passenger seat up and pull back to remove.

3. Remove the two 6mm bolts from the fender bracket and remove.

4. Remove 8mm bolt from back of the solo seat. Lift rear of solo up and pull back to remove.

Installation of Mustang Seat:

1. Slide the solo's nose bracket into the frame receiver at the base of the gas tank.
2. Pull the seat skirt forward to expose the seat bracket. Push seat forward until the bracket aligns with the fender hole. Place a nylon washer between the bracket and the fender, and secure with the stock 8mm bolt using a 10mm wrench.



3. Install two supplied nylon washers and chrome spool washers to the fender with the supplied 6mm x 25mm hex bolts. Tighten with a 10mm wrench.
4. Slide the passenger seat's front bracket into the spool washers and push fully forward.

5. For models with a rear bolt, align the rear bracket with the fender hole, place a nylon washer between the bracket and fender, and secure to the fender with the stock bolt.

6. For models with a fender stud and nut, place supplied nylon washer over fender stud, then lower seat bracket onto the stud. Put the stock chrome washer over the bracket, and secure with the stock nut.

Note: do *not* use the stock steel collar.

Enjoy the comfort and custom look of your new Mustang seat!



Accept no compromises, choose only quality motorcycle seats & backrests.