



## MOUNTING SUGGESTIONS:

### Yamaha V-Star 650 Custom 1998-2017 Solo and Passenger Seat

<b>Hardware:</b>	<b>Solo:</b> Stock 6mm bolts Slotted nut Chrome stud bracket	<b>Passenger seat:</b> Stock rear fender screw or nut White nylon washer
<b>Tools needed:</b>	Metric Allen wrenches and sockets	

#### Removal of Stock Seat:

1. Remove the rear fender screw or nut.



2. Lift rear of passenger seat up and pull back to remove.

3. Remove the two 6mm bolts from the fender bracket, lift rear of solo up and pull back to remove. Leave the two rubber washers on the fender.

## Installation of Mustang Seat:

1. Attach the supplied studded bracket to the fender with the stock bolts. The stud should be toward the rear of the motorcycle.



2. Slide the solo's nose bracket into the frame receiver at the base of the gas tank.
3. Align the rear solo bracket with the stud on the bracket and secure with the provided slotted nut.
4. Align the passenger seat's front bracket with the slotted nut and slide fully forward to engage.

5. For models with a rear bolt, align the rear bracket with the fender hole, place a nylon washer between the bracket and fender, and secure to the fender with the stock bolt.

6. For models with a fender stud and nut, place supplied nylon washer over fender stud, then lower seat bracket onto the stud. Put the stock chrome washer over the bracket, and secure with the stock nut.

**Note: do *not* use the stock steel collar.**

**Enjoy the comfort and custom look of your new Mustang seat!**



Accept no compromises, choose only quality motorcycle seats & backrests.