



MOUNTING SUGGESTIONS:

Harley-Davidson® Sportster 2004-2018 Solo and Passenger Seats

Hardware (Included):	Solo: Fender nut kit	Passenger seat: 1/4"-20 x 1" buttonhead Allen bolt Slotted spool washer
Tools needed:	Phillips screwdriver 5/32" Allen wrench	

Note: Certain Mustang seats will not install on 2007-2009 Sportsters or models with specific fuel tanks. Please be sure your seat is correct for your year and tank size.

Removal of stock seat:

One-piece stock seat:

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach your new Mustang seat.



2. Remove the handstrap if present.

3. Slide the seat up and back to disengage the front bracket and remove the seat.

Installation of Mustang seat:

Solo:

1. If center mount near front of rear fender is plugged, remove plug and install supplied fender nut.
2. Insert nose tab into frame mount under tank.
3. Align rear bracket with fender nut. If installing solo alone, secure the bracket to the fender with the stock screw. If installing a passenger seat, secure to the fender with the supplied $\frac{1}{4}$ "-20 x 1" buttonhead bolt and slotted spool washer.

Note: The shoulder bolt on the frame is not needed to mount the Mustang solo. A hole in the baseplate will accommodate the bolt. Flex the fiberglass pan when installing to ease the hole around the bolt.



Passenger seat:

1. Remove the stock screw mounting the back of the solo and replace with the supplied $\frac{1}{4}$ "-20 x 1" buttonhead bolt and slotted spool washer. The slotted washer should sit directly on top of the solo bracket.
2. Align slotted bracket at front of passenger seat with the slotted spool washer mounted above the solo seat's rear bracket, and slide the seat forward to engage the washer.
3. Align rear bracket with rear mount in fender and secure with stock screw.

Enjoy the comfort and custom look of your new Mustang seat!

