

### **MOUNTING SUGGESTIONS:**

# Harley-Davidson<sup>®</sup> Softail 2000-2015

Solo and Passenger Seats

Stock fender screw

Hardware: Solo: Passenger seat:

Chrome rear bracket

¼"-20 x ½" screw x 2 Chrome washers x 2 Stock fender mounts (or

Mustang part 78032)

Tools needed: Phillips screwdriver

7/16" wrench or nutdriver

These seats will install on the following motorcycles. If your motorcycle is not listed, please contact Mustang for fitment. Passenger seat will fit 2005-up FLSTN Deluxe only if rack is removed. Stock passenger will fit with Mustang solo.

- FLSTC Heritage Classic 2007-2015
- FLSTN Deluxe 2005-2015
- FLSTS Heritage Springer 2000-2003
- FLSTSC Heritage Springer Classic 2005-2007

#### Removal of stock seat:

Two-piece stock seat:

1. Remove the two mounting bolts, if present, from each side of the solo seat. These are not needed to mount the Mustang one-piece seat.



- 2. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach your new Mustang seat.
- 3. Slide the passenger seat up and back to remove.
- 4. Remove the two stock screws from behind the solo, and slide the solo seat up and back to remove.

# Installation of Mustang seat:

#### Solo:

1. Insert the solo's nose tab into the frame mount behind the tank.



2. Align the rear chrome bracket onto the fender studs, put the chrome washers on the bracket, and attach stock slotted nuts (or Mustang part 78032). Tighten securely.

Note: The angles of the steel pan may need to be adjusted slightly to fit your specific bike.

## Passenger seat:

Note: On FLSTN Deluxe, the Mustang passenger seat will not work with the luggage rack. Stock passenger seat will fit with Mustang solo.

- 1. The two notches at the front of the baseplate engage the slotted nuts mounting the solo seat.
- 2. Secure the rear bracket with the stock  $\frac{1}{4}$ "-20 x  $\frac{1}{2}$ " screw.

# Enjoy the comfort and custom look of your new Mustang seat!

