



MOUNTING SUGGESTIONS:

Harley-Davidson® Softail 2000-2006 Solo and Passenger Seats

Hardware:	Solo: Side brackets x 2 Side bolt/washer x 2 1/4"-20 x 3/4" bolts x 2 1/4"-20 x 1/2" screw x 2	Passenger seat: Stock rear bracket (or Mustang part 78037) Stock fender screw
Tools needed:	Phillips screwdriver 7/16" wrench or nutdriver	

These seats will install on the following motorcycles. If your motorcycle is not listed, please contact Mustang for fitment.

- FLST Heritage 2006
- FLSTC Heritage Classic 2000-2006
- FLSTF Fat Boy 2000-2006 and FLSTFSE 2005
- FXST Softail 2000-2005
- FXSTB Night Train 2000-2005
- FXSTS Springer 2000-2005

Note: Mustang solos/passenger seats will not fit with stock solos/passenger seats.

Removal of stock seat:

One-piece stock seat:

1. Remove the two large Allen mounting bolts from each side of the seat.
2. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach your new Mustang seat.
3. Slide the seat up and back to disengage the front bracket and remove the seat.
4. Remove the stock bracket from the rear of the seat.
5. If the stock seat was mounted to smaller mounts screwed into the frame, remove these before mounting the Mustang solo.



Installation of Mustang seat:

Solo alone:

1. Insert the solo's nose tab into the frame mount behind the tank.
2. Align the side brackets with the side frame mounts and install the two large chrome side bolts and washers. Tighten securely.

Note: The angles of the steel pan may need to be adjusted slightly to fit your specific bike.

Solo and passenger seat:

1. Attach the stock rear bracket to the back of the Mustang passenger seat.
2. Remove the two $\frac{1}{4}$ " -20 x $\frac{1}{2}$ " screws from the bottom of the solo, line up the passenger seat's two front brackets with the holes in the solo and re-install the two screws. Tighten securely.
3. Insert the solo's nose tab into the frame mount behind the tank.
4. Optional: align the side brackets with the side frame mounts and re-install the two large Allen bolts. **This is not required when installing with the passenger seat attached. These two brackets can be removed from the solo if desired.**
5. Align the stock rear bracket on the passenger seat with the rear mount in fender and secure with stock screw.

Enjoy the comfort and custom look of your new Mustang seat!



Handcrafted in  the USA

Looking for motorcycle seats & backrests? Visit our website.