



MOUNTING SUGGESTIONS:

Harley-Davidson® 200mm Softail 2006-2017 One-piece Seat

Hardware: Stock fender screw

Tools needed: Phillips screwdriver

These seats will install on the following motorcycles. If your motorcycle is not listed, please contact Mustang for fitment.

- FLSTF, FLSTFB and FLSTFBS Fat Boy 2007-2017
- FLSTSB Cross Bones 2008-2011 (remove springs, supports and frame cover)
- FXST Softail 2006-2007
- FXSTB Night Train 2006-2010
- FXSTC Softail Classic 2007-2010
- FXSTS Springer 2006 and FXSTSSE 2007-2008

Removal of stock seat:

One-piece stock seat:

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach your new Mustang seat.

2. Remove hand strap if present.

3. Slide the seat up and back to disengage the front bracket and remove the seat.



Installation of Mustang seat:

1. Insert nose tab into frame mount under tank.

2. The rear bracket will be 1/2" to 1" above the fender mount. Ensure the seat clears the ECM on the fender and all bumpers are contacting the frame rails and the fender.

3. Align rear bracket with fender nut and secure the bracket to the fender with the stock screw.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product.

Refers to part numbers: 76364, 76386, 76388, 76389, 76390, 76400, 76401, 76403, 76404, 76405, 76982