



MOUNTING SUGGESTIONS:

Honda VTX1800 Neo 2004-08 Solo and Passenger Seat

Hardware:	Solo seat: Stock 8mm Allen bolts x 2	Passenger seat: Stock 6mm screw
Tools needed:	6mm Allen wrench 5mm Allen wrench	

Removal of Stock Seat:

1. Remove the stock 6mm screw from the rear of the passenger seat using a 5mm Allen wrench.



2. Remove the two stock 8mm bolts from either side of the solo using a 6mm Allen wrench.

4. Lift the rear of the seat up, and then slide the seat back to remove.



Installation of Mustang Seat:

1. Slide the solo's front bracket into the frame receptacle under the gas tank. Ensure the bracket is inside the receptacle and not on top of it.
2. Push the solo forward until the two side brackets are aligned with the motorcycle's side mounts. Secure to frame with the two stock 8mm bolts.



3. Slide the passenger's front bracket into the receiver on the back of the solo.



4. Push the passenger seat forward until the rear bracket aligns with the fender mount. Secure the bracket to the fender with the stock 6mm rear screw.

Enjoy the comfort and custom look of your new Mustang seat!



Accept no compromises, choose only quality motorcycle seats & backrests.