



## MOUNTING SUGGESTIONS:

**Harley-Davidson®**  
Sportster/Dyna/Softail 200mm/  
Blackline/Slim - Fender Bib

**Note:** Mustang recommends removal of the fender bib before installing a passenger seat. Mounting a passenger seat over a fender bib may result in damage to the bib, poor seat alignment or other problems.

**Softail 200mm rear tire:** This bib fits with a Mustang solo only.

### Installation of Mustang fender bib:

1. Remove the seat from the motorcycle.
2. Position the fender bib on the fender.
3. Install the solo seat so the seat's rear bracket is on top of the bib. Insert a ¼"-20 screw through the bracket and bib into the fender mount. Leave this loose for now.
4. Secure the back of the bib with the stock rear screw.
5. Adjust the bib for best fit, and secure the solo mounting screw.

78061 shown



Enjoy the custom look of your new Mustang fender bib!



These steps are guidelines to help you install your new Mustang product.

Refers to part numbers: 78030, 78031, 78055, 78056, 78060, 78061, 78104, 78105, 78117, 78118, 78143, 78144