



## MOUNTING SUGGESTIONS:

### Yamaha V-Star 1100 Custom 1999-2011 Solo and Passenger Seat

<b>Hardware:</b>	<b>Solo:</b> Stock solo bracket $\frac{1}{4}$ "-20 x $\frac{3}{4}$ " bolt x 2	<b>Passenger seat:</b> Stock rear nut and chrome washer Small shoulder washer Black nylon washer with $\frac{1}{2}$ " hole
<b>Tools needed:</b>	Metric Allen and socket wrenches	

#### Removal of Stock Seat:

1. Remove the rear fender screw or bolt.

2. Slide the passenger back to remove.



3. Remove the two screws holding the solo bracket to the fender.

4. Slide solo back and up to remove.

5. Remove the rear bracket from the stock solo.

## Installation of Mustang Seat:

1. Install the stock solo bracket to the Mustang solo using the two  $\frac{1}{4}$ "-20 x  $\frac{3}{4}$ " bolts.
2. Engage the solo's nose bracket into the receiver at the base of the gas tank.



3. Secure the solo bracket to the fender with the stock bolts. The passenger seat receiver bracket must be bolted down at the same time.
4. Slide the passenger seat's front bracket into the fender receiver.

5. For models with a rear fender hole and mounting bolt, place the supplied shoulder washer between the fender mount and the seat bracket and secure with stock chrome washer and bolt. For models with a fender stud and a mounting nut, place the ½"-hole washer over the stud, lower the seat bracket over the stud, and secure with stock chrome washer and nut.

**Enjoy the comfort and custom look of your new Mustang seat!**



Handcrafted in  the USA

Looking for motorcycle seats & backrests? Visit our website.