



MOUNTING SUGGESTIONS:

Yamaha V-Star 1100 Classic/Silverado '00-09 – Solo and Passenger Seat

Hardware:	Stock 8mm screws/nut White nylon washer
Tools needed:	Metric wrenches

Removal of stock seat:

1. Remove the 8mm screw or nut from the fender.

2. Slide passenger seat back to remove.



3. Remove 8mm screw behind the solo.

4. Slide solo back and up to remove.

Installation of Mustang seat:

1. Slide nose bracket on the front of the solo into the receiver at the base of the gas tank.

2. Secure the rear of the solo to the fender with the stock 8mm screw.

3. Slide the passenger seat's front bracket under the fender receiver and align the rear bracket with the fender mount.

4. On models with a fender stud, put the white nylon washer between the fender and the seat's rear bracket and secure with the stock nut. On models with a fender hole, secure the bracket to the fender with the stock 8mm screw.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product.

Refers to part numbers: 75910, 75912, 75913, 75914, 75916, 75917, 79240, 79242, 79243, 79244, 79246, 79247