



MOUNTING SUGGESTIONS:

Harley-Davidson® FXFB Fat Bob 2018 Solo and Passenger Seat

Hardware (Included):	Solo: <i>(none)</i>	Passenger seat: 1/4"-20 x 1" buttonhead Allen bolt Slotted spool washer
Tools needed:	Flat screwdriver 5/8" hex wrench 5/32" Allen wrench	

Removal of Stock Seat:

1. Remove the rear 1/4"-20 fender screw with a screwdriver and set it aside. The stock rear fender screw will be used to attach your new Mustang seat.
2. Slide the seat up and back to disengage the front bracket and remove the seat.



3. Remove the handstrap with a 5/8" hex wrench.

Installation of Mustang seat:

Solo:

1. Remove the plug from the second fender mount located appx. 2" behind the handstrap fender nut. Remove the plastic C-clip from the handstrap fender nut and remove the nut from under the fender. **Do not lose this clip.**
2. Install the fender nut in the second fender hole using the C-clip. Insert the plug into the forward hole.



3. Engage the Mustang solo's front mounting bracket into the frame mount behind the tank.
4. Align the rear bracket with the fender nut. If installing the solo alone, secure the bracket to the fender with the stock screw. If installing a passenger seat, secure to the fender with the supplied $\frac{1}{4}$ "-20 x 1" buttonhead bolt and slotted spool washer.

Passenger seat:

1. Remove the stock screw mounting the back of the solo and replace with the supplied $\frac{1}{4}$ "-20 x 1" buttonhead bolt and slotted spool washer. The slotted washer should sit directly on top of the solo bracket.

2. Align the slot at the front of the Mustang passenger seat with the slotted spool washer mounted above the solo seat's rear bracket, and slide the seat forward to engage the washer.



3. Align the rear bracket with the rear fender nut and secure with the stock screw.

Enjoy the comfort and custom look of your new Mustang seat!



View [other motorcycle seats & backrests](#) made by [Mustang](#) on our website.