



MOUNTING SUGGESTIONS:

Harley-Davidson® FL "Air Ride" style 1983-2018 Solo Seat

Hardware: $\frac{5}{16}$ "-18 serrated nuts x 3

Tools needed: $\frac{1}{2}$ " open-end wrench

Removal of stock seat:

1. Pivot seat up to reveal mounting bolts and unscrew the bolts from the seat. These will not be used to mount your Mustang solo.
2. Remove stock seat from the pivoting bracket.



Installation of Mustang seat:

Note: The pivoting bracket has changed through the years, but the Mustang solo will fit all versions.

1. Remove the three hex nuts from the studs on the bottom of the Mustang solo.
2. Position Mustang solo onto pivoting bracket and align the three studs with the holes in the bracket.
3. Install the three hex nuts onto the studs and tighten securely.
4. Pivot seat into riding position.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product.

Refers to part numbers: 76455, 76456, 79548, 79549