



MOUNTING SUGGESTIONS:

**Harley-Davidson®
FL Touring 1993-2016
Saddlebag & Tour-Pak® Lid Covers**

Installation of Mustang lid cover:

1. For easiest install, allow the lid cover to warm so the vinyl is more pliable. Put it in its bag, and place it in a warm location (such as on a dashboard on a sunny day) for about 10-20 minutes. **Do not overheat the cover as the vinyl may melt.**



2. Position the front edge of the lid cover onto the front of the lid.

3. Stretch the two back corners onto the lid, one at a time. The fit will be extremely tight.

4. Adjust the cover on the lid for best fit.

5. The lid may be difficult to close and latch the first time. Once the vinyl has been compressed under the lid, the lid will operate normally.

Enjoy the custom look of your new Mustang lid covers!



Buy quality motorcycle custom accessories & trim in our online store.