



VStream™ Windscreen
Installation and Owner's Manual
N20302 for FJR 1300 06-
Quantum™ Coated Lexan® polycarbonate

Attention



Special notes and cautionary measures which can prevent damage to the accessory or motorcycle.

Note:



Tips for facilitation of operation, control and adjustment, as well as maintenance work.



TOOLS REQUIRED:
 Phillips Screwdriver
 3mm Hex Key



Right and left side of motorcycle is determined while sitting on the bike.

PARTS LIST

<u>Index</u>	<u>Description</u>	<u>Qty.</u>
1	Windshield, Quantum Coated Lexan® polycarbonate	1

INSTALLATION



Retain all fasteners and front plate, as they will be reused.

1. Remove the 2 screws holding plastic front plate to top surface of windscreen. **Figure 1 (3mm Hex Key)**
2. Remove the 7 screws holding the stock windscreen to the motorcycle. **(Phillips Screwdriver)**
3. Place VStream Windscreen into position on motorcycle. Secure at all 7 locations with the stock screws. Tighten the screws firmly. **Do not over tighten. Figure 2 (Phillips Screwdriver)**
4. Replace front plate on outside of windscreen with stock screws. **(3mm Hex Key)**



Figure 1



Figure 2

MAINTENANCE

Cleaning: Wash with a clean soft cloth, plenty of warm water and, if necessary, a non-abrasive soap such as dish-washing liquid. Flannel or soft chamois make good cleaning cloths.

Paint, glue residue removal: Moisten cotton with a small amount of Naphtha or Turpentine followed by a wash as above. Do not clean polycarbonate in hot sun or high temperatures. Do not clean the screen with glass cleaners. Do not use rain protective products on the screen. The solvent action of the alcohol in these products will destroy the screen. Do not allow brake fluid, alcohol, or strong solvents to contact the screen.