

Note: N764 Chrome Lower are engineered to install to a National Cycle Windshield Mount Kit. These Kits include: Kit CTA, CJ Series, B Series, or J Series.



Tool list will vary depending on
Windshield Mount Kit used.
1/2" Wrench or
5/32" Hex Key and two, 7/16" wrenches.

Kit N764 Contains: One Set Chrome Lower.

Preparation

1. Install the Windshield clamps to the motorcycle forks. Do Not Install Windshield.

INSTALLATION of N764

1. Select the appropriate chrome lower for the left or right side of the motorcycle.
2. Position the windshield bracket "A" directly to the fork clamp "B". **DO NOT USE** the flat bracket from the windshield kit.
3. Position the Chrome Lower "C" to the outside of the Windshield Bracket.
4. Secure with Screws and Acorn Nuts from the windshield mount kit.
5. Check to be sure your Chrome Lower do not contact any part of the motorcycle at a full turn left and right. Make any necessary adjustments.
6. Fully tighten socket head screws, bolts, and nuts.

MAINTENANCE / CAUTION

The high quality chrome finish of your National Cycle Chrome Lower can be maintained with any quality chrome cleaner and / or polish applied with a soft cloth.

Check hardware for tightness regularly. Never ride with loose mounting hardware. Check to be sure your Chrome Lower do not contact any part of the motorcycle at a full turn left and right. Correct any problem before using the motorcycle.

