NEW CYCLES INSTALLATION INSTRUCTIONS

BMW R9T

FENDER ELIMINATOR

- Remove passenger seat using T30 torx, and then remove rider seat (picture 1)
- Remove 4 stock bolts underneath bike holding plastic shield (picture 2)
- Remove 4 stock bolts up top, removing stock fender in the process (picture 3)

Removing the passenger peg bracket is optional so only follow if you choose to do so. If passenger peg bracket is off, you will need to use seat pod in rear. If passenger peg bracket is on the bike, you may use either stock seat or seat pod.

- Unbolt 4 bolts holding passenger peg bracket using T40 torx (picture 4)
- 2 Using the same T40 torx, unbolt 2 stock bolts removing brake lever / peg (picture 5)









NEW CLES INSTALLATION INSTRUCTIONS

FENDER ELIMINATOR

- With supplied hardware, mount license plate bracket to upper lens bracket and then bolt upper lens plate onto bike (picture 6/7)
- With remaining stainless bolts, bolt lower lens plate onto bike (picture 8)
- 3 Plug harness into bike
- 4 Put seat(s) and/or pod back on bike and ride safe







