

Instructions:

Thoroughly clean the rim with a strong degreaser to remove all oil and grease residue.

- 1. Make sure the rim is clean
- 2. Peel backing paper off the Pro-Seal
- 3. Lightly align the Pro-Seal
- 4. Once the Pro-Seal is aligned, press firmly for a perfect fit.

Works great with: FLO Air Filters FilterSkins



View other motorcycle air intake & filters made by PC Racing on our website.