POWERMADD® Large Mirror Kit

Installation Instructions for Part No. 34257 Requires Mirror Kit No. 34289

HARDWARE INCLUDED:		TOOLS REQUIRED:
Oty	Description	Description

Oty Description

Mirror 1 Mirror Base Screw (4x3/4") 1

2 Adhesive squares

Grease Packet

Phillips screw driver Standard screw driver

* Included in kit

STEP 1: Choose which side you will be installing the large mirror kit to and remove your current mirror(s) from your handguard(s).

STEP 2: Remove the Phillips screw from the back of the mirror.

STEP 3: Pry off the small mirror from the mirror bracket by using your fingers or a standard screw driver. It is being held on with double sided tape.

STEP 4: Clean the mirror bracket of any dirt, debris, foam and moisture. You do not need to remove the old adhesive.

STEP 5: Remove the mask from the two pieces of double sided tape and place them on the mirror bracket. **Photo 1**.

STEP 6: Insert the provided screw into the back of the mirror bracket so at least 1/4" of the screw can be seen. **Photo 2**.

STEP 7: Using the screw as a guide, place the large mirror extension on the mirror bracket and align as shown in **photo 3**.

STEP 8: Press down in the center of the mirror extension to make sure the double side tape adheres.

STEP 9: Use the supplied grease packet and apply grease to the areas shown in white. Photo 3

STEP 10: Remove the mask from the back of the large mirror base plate and once again using the screw as a guide, place the large mirror base on to the large mirror extension. Using a Phillips screw driver, get the screw started into the large mirror base plate. Do not tighten at this time

STEP 11: Snap the large mirror into place on the large mirror base plate.

STEP 12: Tighten the screw being careful not to over tighten. You should be able to rotate the large mirror. If it is difficult to rotate mirror back the screw off a little.









POWERMADD® Large Mirror Kit

Installation Instructions for Part No. 34257



Requires Mirror Kit Part No. 34289