Installation Instructions



For use on PowerMadd Star Series, TrailStar and Sentinel handguards.

Step 1	Determine the correct side by making sure the PowerMadd logo faces up in the front. Open the Gauntlet and turn it inside out.	
Step 2	Slide the Gauntlet onto the handguard so that the two elastic straps go over the guard.	
Step 3	Continue sliding the Gauntlet onto the guard until the straps are about halfway across the guard.	
Step 4	In this position you should be able to insert the inside edge of the handguard into the pocket in the Gauntlet.	
Step 5	Keeping the inside edge in the pocket, slide the Gauntlet back towards the outer edge of the guard and reposition the straps on the outer edge of the guard.	

Handguard Gauntlet Part # 34258

Installation Instructions



Step 6	Pull the Gauntlet around the guard, turning the Gauntlet correct side out.	
Step 7	Close the inside of the Gauntlet by using the Hook and loop fastener straps.	
Step 8	Cinch the strap through the buckle to close the Gauntlet around your handlebars.	
Step 9	Repeat for other side.	