

Sentinel Handguard Mirror



Installation Instructions for Part No. 34455

Hardware Included:

- 2 – Short button head screws
- 2 – Long button head screws
- 2 – Lock nuts
- 2 – Springs
- 2 – 6mm washers
- 2 – square nuts(not used)

Tools Required:

- 4mm hex wrench
- 10mm wrench
- 1/4" drill bit
- Drill
- Drill punch

PLEASE READ ALL INSTRUCTIONS CAREFULLY PRIOR TO INSTALLATION

NOTE: These instructions will explain how to install one side. Then repeat the instructions for the other side.

STEP 1: Hold the left mirror onto the Left Sentinel Handguard as show in **Photo 1**. Mark the hole with a marker. Make sure the mirror is situated in the recesses of the handguard. Proper placement of the hole is crucial for the mirror to work properly. Using the punch, mark the hole and then using a 1/4" drill bit drill the hole.

Note: Some Sentinel Handguards may already have a drilling pilot hole.

STEP 2: **For a FIXED mirror:** Attach the mirror to the handguard by inserting the short button head screw through the front of the handguard and then the mirror. Use the 6mm washer and lock nut to secure the mirror to the Sentinel handguard.

For a FOLDING mirror: Attach the mirror to the handguard by inserting the long button head screw through the front of the handguard and then the mirror. Slide the washer onto the screw, then the spring and secure with the lock nut until the screw is flush with the end of the lock nut. (see photo 2) To fold, simply rotate the mirror downward. (see photo 3)

STEP 3: Once mounted, adjust mirrors by rotating them to the desired position.

NOTE: Folding mirror option will not work with the Sentinel Armor (34477).



Photo 1



Photo 2



Photo 3