

# POWERMADD®

## Fuzion Handguard

### Installation Instructions for Part No. 34500

#### HARDWARE INCLUDED:

Qty	Description
1	Handguard (pair)
8	Pan Head Screws
8	Lock Nuts
2	Mount Brackets

#### TOOLS REQUIRED:

4mm Hex Key Wrench

**Requires a Sentinel mount kit: 34450 or 34452 or 34454**

**STEP 1:** Follow the instructions for the Sentinel mount kit you purchased until step 6 for the 34450 and 34452 and Step 4 for the 34454 mount kit.

**STEP 2:** Determine how you would like the guard mounted. Photo 1 will bring the guard closer to the bars and Photo 2 will bring the guard further away.

**STEP 3:** Insert 4 of the lock nuts into the mounting bracket.

**STEP 4:** Slide the pan head screws through the front of the Fuzion handguard through the mount bracket into the lock nuts. Tighten with a 4mm hex key wrench. Repeat step 4 for both sides.

**STEP 5:** The mount is installed onto the bracket as shown in the photos below. Hold the handguard up to the mounting bracket and determine the optimal location. The optimal location is a personal preference. For the best hand coverage, the end of the handguard should extend beyond the handle bar about 1". Once you have determined the location of the mounting bracket within the handguard mounting tabs, slide the M6 x 75mm bolt through one mounting tab and use the available large and small spacers to position the bracket in the desired location (All spacers need to be used). There are 7 possible positions available.



**Photo 1**



**Photo 2**

**STEP 5:** At this time go back and check the torque of all fasteners. All fasteners may need to be retightened after the first ride. Check the tightness of the bracket and handguard before each ride.

**Note:** If using a cover, Fuzion handguards may deform. They will recover after a short period or can be manually manipulated to the original shape. If covered for extended periods of time in excessive heat (such as summer snowmobile storage), deformation may be permanent.