

POWERMADD® Grab Strap

Installation Instructions for Part No. 43588

HARDWARE INCLUDED:

Qty	Description
1	Grab Strap w/brackets
2	Long Screws
2	Lock Nuts
2	Washers

TOOLS REQUIRED:

7/16" Wrench
5/32" Hex Wrench

Note: Due to the stresses that the Grab Strap will need to withstand, the mounting brackets are designed to be a tight fit onto your handle bars. Determine your mounting location carefully as the clamps may scratch your handle bars.

STEP 1: The Grab Strap requires approximately ½" of space on your handlebars for the mounting brackets. Remove the handlebar cover from your snowmobile or ATV if you have one.

STEP 2: Spread the mounting brackets out to make sure they easily fit over your handlebars. With rib side of the rubber strap down, place the mounting brackets over your handlebars. Squeeze the brackets back together. Slide the screw through each clamp and install the flat washer and lock nut onto the screw.

STEP 3: Before you tighten the screws, make sure you can still operate all of your controls and levers properly. Once in position, tighten the screws until the clamp is firmly fastened to handlebar.

STEP 4: Re-install handlebar cover if necessary.

STEP 5: Check the screws after the first ride and at least once a season to make sure they are still tight. .



POWERMADD®

Looking for dependable motorcycle frames and body? Rely on PowerMadd for quality and long-lasting products.