



## Fully Adjustable Lowering Link Installation Instructions

### Horseshoe Link Style

1. Remove OEM links.
2. Install PSR's Lowering Link with center hex bodies offset toward the rear of the bike. (GSXR1000 07-08 is opposite).
3. Use the aluminum spacer in the front.
4. Use the included longer bolt in the rear.
5. Tighten lowering link lock-nuts. Use Red Loctite on all threads.
6. Inspect bike height.
7. Adjust the link as desired (Not to exceed the maximum center to center length).
8. Be sure to adjust each link equally and in the same direction.

The maximum hole-to-hole, center-to-center length for each of these links, not to be exceeded is:

06-07 GSXR 600/750 8½"

07-08 GSXR 1000 8½"

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. PSR is not responsible for any losses, damages or claims resulting from injuries sustained or alleges to have been sustained by the installation of this product not installed by a certified mechanic experienced in the installation of component parts on motorcycles. PSR is not responsible for the functionality of the product not properly installed or under circumstances in which there has been a modification to the product by any person not employed by PSR.