



## PSR Dual Sport Kickstand Installation Instructions 08-04502 / DK3

**\*\*Removable Thread Locking Compound is recommended on all bolt threads\*\***

1. Verify bike model & kickstand application before installation!
2. Place bike securely on a center stand recommended.
3. Remove lower chain roller bolt. Be sure to note all parts removed for re-assembly.
4. Remove left lower subframe to mainframe bolt.
5. Install the supplied lower kickstand mounting bracket onto the frame at the lower chain roller boss by sliding the counter bore onto the frame boss.
6. The chain roller should go back into place but with the supplied lower kickstand mounting bracket between it and the frame. **DO NOT TIGHTEN YET.** The lower kickstand mounting bracket needs to pivot to align with the lower hole of the main kickstand mount.
7. Install PSR kickstand onto the bike with supplied M8x30mm flat head bolt at the subframe and mainframe bolt location. **DO NOT TIGHTEN YET.**
8. Line up and install the other supplied M8x30mm flat head bolt thru the lower kickstand mounting hole into the lower kickstand mounting bracket.
9. Tighten ALL three bolts. (two main kickstand mounting bolts and one lower kickstand mounting bracket bolt.)
10. Rotate kickstand through its entire travel and check for clearance prior to use.

### Usage & Maintenance of PSR Dual Sport Kickstand:

1. Check all hardwares for tightness before each ride.
2. Do Not Start the bike with kickstand down.
3. Do Not Kickstart the bike with kickstand down.
4. Clean and lubricate the kickstand pivot area after each ride.

Accept no compromises, choose only quality motorcycle frame and body.