

## MOUNTING INSTRUCTIONS

### WINDSHIELD MODEL CUSTOM II

Ref.: 0336

ID.	DESCRIPTION	REF.	QTY.
1	Windshield	I0149H/W	1
2	M5 DIN982 nut	TUERCA-D982-746	4
3	M5x13 phillips screw	TORNIPS10---233	4
4	M5x20 DIN912 screw	TORNI-AD912-464	4
5	Semi-clamp ball-joint nut	BRIROT01-I-PR16	2
5	Semi-clamp ball-joint screw	BRIROT02-I-PR16	2
6	Medium-spacer Ø22mm	CAS29-22-0-PR16	4
7	Medium-spacer Ø26mm	CAS29-26-0-PR16	4
8	M8x50 DIN912 screw	TORNI-D912--631	2
9	M8 DIN982 nut	TUEA-D985.8-M8-	2
10	Rod guide	FIXVARLL-0-PR16	2
11	Front clamp handlebar	BRIDAANT-0-PR16	2
11	Rear clamp handlebar	BRIDAPOS-0-PR16	2
12	Rod Dim. 4x20mm Inox	VARIL14X20--576	2
13	Ball bearing set	CJROTULA-0-P200	2
13	Rod with ball bearing Dim. 9x200mm	VARILF9X200-591	2
14	Support set	CONJU-S3PCC-003	2
15	Rubber outer stop	TOPEE-VPGT--8/4	2
16	Trim	RIBETEHP--900H	1
17	M6 DIN912 screw cap	TAPA--CH11450E	2

