

REAR MUDGUARD HONDA CBR600F 99'-07'
REF:1436



INSTRUCTIONS TO ASSEMBLE

- 1- Dismount the original chainguards.
- 2- Dismount the rear brake guides (2). Place the hardware supplied (1) over the guides, as the figure shows, using the M6x20 white screws. Tigth it without pressing.
- 3- Place the silenblocks in the rear hugger drills.
- 4- Mount the hugger using the M6x15 allen screws in the drills of the chainguard fixation. In the hardware use the M6x20 allen screws jointly with the M6 nuts.
- 5- Adjust the hugger with the tire through the regulation that the iron fittings offer, and tighten them all.
- 6- Check them periodically, and tight the fixations.
- 7- In case your motorcycle has other accessories, observe that it does not interfere with the hugger.

Material supplied to assemble the mudguard:

DESCRIPTION	QTT
<i>M6x20 screws DIN6921</i>	2
<i>M6x15 allen screws DIN1001</i>	2
<i>M6x20allen screws DIN1001</i>	2
<i>M6 nuts</i>	2
<i>Iron fittings</i>	1
<i>Wellnuts</i>	4

