

# REAR MUDGUARD SUZUKI BANDIT 1200/S 95'-05'

REF:1462



## INSTRUCTIONS TO ASSEMBLE

- 1- Dismount the original chainguard.
- 2- Pull up the brake guide (2) and take the rear break line out (3) to be able to place the bridle (1) in the swing arm (4). Use the hexagon M6x15 screws and the nuts. Do not tighten. A foam sticker is served to put on the bridle as a protection of the swing arm .
- 3- Place the silenblocks in the rear mudguard drills.
- 4- Mount the rear mudguard using the M6x15 allen screws in the fixations of the chainguard. Use the M6x20 allen screws jointly with the M6 nuts in the hardware.
- 5- Adjust the mudguards with the tire through the regulation that the iron fittings offer, and tighten them all.
- 6- Check them periodically, and tighten the fixations.
- 7- In case your motorecycle has other accessories, observe that it does not interfere with the mudguard.

## Material supplied to assemble the mudguard:

DESCRIPTION		QTY
<i>Tornillo Allen M6x20 DIN1001</i>	<i>M6x20 allen screws</i>	2
<i>Tornillo Allen M6x15 DIN1001</i>	<i>M6x15 allen screws</i>	2
<i>Tornillo Hexagonal M6x15 DIN933</i>	<i>M6x15 Hexagon screws</i>	2
<i>Tuercas grafiladas M6 DIN6923</i>	<i>M6 nuts</i>	4
<i>Herraje</i>	<i>Iron fittings</i>	1
<i>Silenblocks</i>	<i>Wellnuts</i>	4
<i>Espuma adhesiva</i>	<i>Foam Sticker</i>	1

