

**LICENSE SUPPORT HONDA CBR600RR
03' -06'**

REF:1612



INSTRUCTIONS TO ASSEMBLE

- 1- Dismount the original license support (in order to make easy the assembling process we recommend to dismount the front and rear seat base. Next, take off the seat that is fixed with four fasteners).
- 2- Mount the side supports using the M6x10 allen screws (positions 3 and 4). The turn signals must be mounted on position 5. It is supplied two plastic bridles to fix the turn signal cable in the drill 6. Mount next the central support using the M6x10 hexagonal screws (2) and the M6 nuts (1). Adjusts the side supports through the regulation that the group offer, and tighten them all.

Material supplied to assemble the license support:

DENOMINACIÓN	CANTIDAD
M6X10 screw DIN6921	2
M6 Nut DIN 6923	2
M6x10 allen screw DIN 1001	4
2.5x98 plastic bridles	2
Support c\black	3
Reflector	1
Support for reflector	1

