



REF.1762

INSTRUCTIONS TO ASSEMBLE

- 1- Dismount the original license support.
- 2- Mount the supplied support using the original fasteners and nuts that are supplied "A".
- 3- The turn signals cables can be fasten through the plastic bridles supplied in the slot "C".

Material supplied to assemble the license support:

2	Plastic Bridle	
4	M6 Nut DIN6923	
1	Bracket c/black	
1	Reflector	
1	Support for reflector	

