

**FRONT-AXLE REAR-AXLE SLIDERS PH19  
UNIVERSAL**

**REF: 20097N**

**MOUNTING INSTRUCTIONS**

- 1) Remove the slider (1) from the set supplied.
- 2) Without removing the other slider (2), place the rod (3) through the axle from the left side.
- 3) Mount the slider (1), fastening the set with the washer (5) and nut (4).

Material supplied:

POSICIÓN	DENOMINACIÓN		CANTIDAD
1	PROFOR15-2-0759	Right Slider	1
2	PROFOR16-2-0760	Left Slider	1
3	VARIFO05-2-0005 Long. 390	Rod	1
4		M6 nut DIN985	2
5		M6 washers DIN125	2
6		Caps	2

**4**  **86 lbf/in - Tightening torque**

