

PHB19 FRONT-AXLE SLIDERS ADAPTABLE TO:

DUCATI MONSTER 797 17'-

DUCATI MONSTER 821 14'-

SUPERSPORT 939/S 17'-

REF: 20109N

MOUNTING INSTRUCTIONS

- 1) Remove the slider (1) from the set supplied.
- 2) Without removing the other slider (2), place the rod (3) through the axle from the right side.
- 3) Mount the slider (1), fastening the set with the washer (5) and nut (4).

Material supplied:

POSICIÓN	DENOMINACIÓN	CANTIDAD
1	Right Slider	1
2	Left Slider	1
3	Rod	1
4	M6 nut DIN985	2
5	M6 washers DIN125	2
6	Caps	2

TIGHTEN NUT M6 WITH A TORQUE OF 9,7Nm

