

KTM 1290 SUPERDUKE R '20

REF 20450N

R19 CRASH PADS

INSTRUCTIONS TO ASSEMBLE

Remove the fasteners that subject the chassis to the engine. Mount the protectors on each own side as the figure below shows. Tight the set, and place the caps. All the screws replaced, should be tightened to the torque specified in the oem maintenance manual for your motorcycle. if no torque specifications are provided in the oem maintenance manual, may be used 54Nm for all M10 screws. Medium strength liquid thread-locker (i.e. "Loctite") should be used to secure all screws, bolts and nuts. All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque.

FOR TO ASSEMBLE THE CRASH PADS, IF YOU ARE NOT A TRAINED MECHANIC, PLEASE CONTACT A SPECIALIST. MOTOPLASTIC, S.A. TAKES NO RESPONSIBILITY FOR DAMAGES CAUSED BY IMPROPER INSTALLATION. THE USE OF CRASH PADS DO NOT GUARANTEE A FULL PROTECTION IN CASE OF ACCIDENT. MOTOPLASTIC-PUIG DECLINE ANY RESPONSIBILITY IN CASE OF MOTORCYCLE DAMAGE.

ID.	PART	DESCRIPCIÓN	DESCRIPTION	QTY.	REF.:
1			Plastic cover	2	TAPAPROTECR19-D/I
2			M10/150x120 DIN912 screw	2	TORNIAD912-0353
3			M10 DIN6798/A glover washer	2	M2AM10DIN6798ZB
4			M10 DIN125/A washer	2	M2AM10DIN125AZB
5			R19 Nylon Protector	2	PROTECNLR19-145
6			Aluminum spacer (Black)	2	CASQU294-0-1594

KTM 1290 SUPERDUKE R '20

REF
20450N

MOUNTING INSTRUCTIONS

1

The right side assembly is shown as an example, so the same steps can be performed for the left side assembly.

ASSEMBLY

