

**REAR MUDGUARD FOR HONDA CBR600RR 05'-06'**  
**REF: 2519**



**INSTRUCTIONS TO ASSEMBLE**

- 1- *Dismount the original hugger.*
- 2- *Place the wellnuts in the hugger drills.*
- 3- *Place the hugger in order to have the brake line and guide above the hugger. Fix it using the original screws. Tight the hardware.*
- 4- *Check them periodically, and tighten the fixations.*
- 5- *In case your motorcycle has other accessories, observe that it does not interfere with the mudguard.*

**Material supplied to assemble the mudguard:**

DESCRIPTION		QTT
Silenblocks	Wellnuts	3

Rely on premium motorcycle frames & body by Puig if you're looking for quality and efficiency.