



**REF: 4127**

**INSTRUCTIONS TO ASSEMBLE**

- 1- Dismount the original chainguard.
- 2- Dismount the rear brake line guides (1). Place the bridle supplied (with the M6 nuts inserted in position 4) between the two guides, as the figure shows, right next to the closest guide to the rear axle. Use the M6x20 (position 2) and the M6x10 (position 3) allen screws jointly with the M6 special nuts. Fasten the fixation without pressing.
- 3- Adjust the hugger with the tire through the regulation that the hardware offer, and tighten them all.
- 4- Check them periodically, and tight the fixations.
- 5- In case your motorcycle has other accessories, observe that it does not interfere with the hugger.

**Material supplied to assemble the hugger:**

	DESCRIPTION	QTY
	M6x20 Allen screws	1
	M6x15 Allen screws	4
	M6x10 Allen screws	1
	M6 special nuts	2
	Hardware	1
	Wellnuts	4

