

REF: 4736N



**MOUNTING INSTRUCTIONS**

- 1- Dismount the original bracket.
- 2- It is recommended to mount the turn signals and light, tightening the cables in the slots of the bracket with the plastic bridles (8) supplied.
- 3- Mount the black bracket (4). Use the fasteners supplied (1) jointly with the original washers (2) in order to fix the metal arrowheads (3). Next, place the bracket (4) and tight it with the washers (5) and nuts (6) supplied. Once the cables are guided to the interior of the motorcycle, close the gap with the cap (7) and locknuts (6).

**Material supplied to assemble:**

	DESCRIPTION	QTY
1	Black M6x40 DIN933 Hexagonal fastener	4
3	Ø20x5 Metal arrowhead	4
4	Black bracket	1
5	Ø18Ø6x1,5 DIN9021 black washer	4
6	Silver M6 DIN6923 locknut	8
7	Cap in black	1
8	Plastic Bridles	2

