



MOUNTING INSTRUCTIONS

- 1) Dismount the original support.
- 2) Mount the supplied bracket using the M6x10 screws in A, B, C, and D positions. Use the plastic bridles to fix the blinkers cables in the E slot.

Material supplied:

POSICIÓN	DENOMINACIÓN	CANTIDAD
A,B,C,D	M6x10 allen screws	4
	Bracket c\black	1
E	Plastic bridles	2
	Reflector	1
	Support for reflector	1

