

## INSTRUCTIONS TO ASSEMBLE

- 1- Dismount the original chainguard and the rear brake line guide.
- 2- Mount the wellnuts (4) on the rear hugger.
- 3- Tight the rear hugger using the M6x15 screws supplied.
- 4- Check them periodically, and tighten the fixations.
- 5- In case your motorcycle has other accessories, observe that it does not interfere with the hugger.

## Material supplied to assemble the hugger:

POS.	DESCRIPTION	QTT.
1	Wellnuts	4
2	Black M6x15 screw DIN1001	4



