

MOUNTING INSTRUCTIONS

CRASH PADS FOR HYOSUNG GT650R

Ref.: 6402

INSTRUCTIONS TO ASSEMBLE

Remove the fasteners that subject the chassis to the engine, on the point marked below (and the opposite side). Mount the protectors on each own side as the figure below shows. Tight the set, and place the caps. Mounting instructions for R12 sliders caps. Pull with pliers from tips A marked on the figure below. Once the cap is settled, cut the tips A. In case you need to dismount the caps, spare ones are supplied to repeat the process.

ID.	DESCRIPTION	QTY.
1	Plastic caps	2
2	M10/150X100 fastener	2
3	Ø20ext. Ø10int x2 washer	4
4	Nylon protector	2
5	Aluminium metal arrowhead	2
6	Right off set	1
7	Left off set	1
8	M10/125X80 DIN912 fastener	1
9	M10/125X130 DIN912 fastener	1
10	Right aluminium arrowhead	1
11	Left aluminium arrowhead	1
12	Metal arrowhead "no-turn"	4
13	Black M6X15 DIN1001 fastener	4
14	M10 nut	2

FOR TO ASSEMBLE THE CRASH PADS, IF YOU ARE NOT A TRAINED MECHANIC, PLEASE CONTACT A SPECIALIST. MOTOPLASTIC, S.A. TAKES NO RESPONSIBILITY FOR DAMAGES CAUSED BY IMPROPER INSTALLATION. THE USE OF CRASH PADS DO NOT GUARANTEE A FULL PROTECTION IN CASE OF ACCIDENT. MOTOPLASTIC-PUIG DECLINE ANY RESPONSIBILITY IN CASE OF MOTORCYCLE DAMAGE.

