

## INSTRUCTIONS TO ASSEMBLE

Remove the fasteners that subject the chassis to the engine, on the point marked below (and the opposite side). Mount the protectors on each own side as the figure below shows. Tight the set, and place the caps. Mounting instructions for R12 sliders caps. Pull with pliers from tips A marked on the figure below. Once the cap is settled, cut the tips A. In case you need to dismount the caps, spare ones are supplied to repeat the process.

ID.	DESCRIPTION	QTY.
1	Plastic caps	4
2	M10/150X40 screw	1
3	M10/150X75 screw	1
4	Ø20ext. Ø10int. x2 washer	2
5	Nylon protector	2
6	Aluminium metal arrowhead right hand	1
7	Aluminium metal arrowhead left hand	1
8	Ofset	2
9	M8x60 DIN912 screw	4
10	Metal arrowhead	4
11	Nut M10 DIN985	2

FOR TO ASSEMBLE THE CRASH PADS, IF YOU ARE NOT A TRAINED MECHANIC, PLEASE CONTACT A SPECIALIST. MOTOPLASTIC, S.A. TAKES NO RESPONSIBILITY FOR DAMAGES CAUSED BY IMPROPER INSTALLATION. THE USE OF CRASH PADS DO NOT GUARANTEE A FULL PROTECTION IN CASE OF ACCIDENT. MOTOPLASTIC-PUIG DECLINE ANY RESPONSIBILITY IN CASE OF MOTORCYCLE DAMAGE.

## MOUNTING INSTRUCTIONS

### CRASH PADS R12 FOR KAWASAKI Z800 13'-

Ref.: 6563

