



**FRONT-AXLE SLIDERS ADAPTABLE TO:
BMW C-600 Sport '12-**

REF: 6813N

MOUNTING INSTRUCTIONS

- 1) Remove the slider (1) from the set supplied.
- 2) Without removing the other slider (2), place the rod (3) through the axle from the right side.
- 3) Mount the slider (1), fastening the set with the washer (5) and nut (4).

Material supplied:

ID.	DESCRIPTION	QTY
1	Left Slider	1
2	Right Slider	1
3	Rod	1
4	M6 nut DIN985	2
5	M6 washers DIN125	2

