

INSTRUCTIONS TO ASSEMBLE

Remove the fasteners that subject the chassis to the engine, on the point marked below (and the opposite side). Mount the protectors on each own side as the figure below shows. Tight the set, and place the caps.

All the screws replaced, should be tightened to the torque specified in the oem maintenance manual for your motorcycle. if no torque specifications are provided in the oem maintenance manual, may be used 54Nm for all M10 screws.

Medium strength liquid thread-locker (i.e., "Loctite") should be used to secure all screws, bolts and nuts.

All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque.

ID.	DESCRIPTION	QTY.
1		2
2	M10/150 x80 screw	1
3	M10/150 x90 screw	1
4	Washer M10 DIN125/A	6
5	Nylon protector	2
6	Metal arrowhead right hand side	1
7	Metal arrowhead left hand side	1
8	Right offset	1
9	Left offset	1
10	Metal arrowhead right hand side Ø24x10	1
11	Metal arrowhead right hand side Ø24x25	1
12	Metal arrowhead left hand side Ø24x18	1
13	Metal arrowhead left hand side Ø24x22	1
14	M10/125 x70 screw	1
15	M10/125 x80 screw	3
16	Nut M10 DIN6923	2
17	M10 Plastic cap screw	4

FOR TO ASSEMBLE THE CRASH PADS, IF YOU ARE NOT A TRAINED MECHANIC, PLEASE CONTACT A SPECIALIST. MOTOPLASTIC, S.A. TAKES NO RESPONSIBILITY FOR DAMAGES CAUSED BY IMPROPER INSTALLATION. THE USE OF CRASH PADS DO NOT GUARANTEE A FULL PROTECTION IN CASE OF ACCIDENT. MOTOPLASTIC-PUIG DECLINE ANY RESPONSIBILITY IN CASE OF MOTORCYCLE DAMAGE.

MOUNTING INSTRUCTIONS

FRAME SLIDERS FOR YAMAHA MT09

Ref.: 7316N

