

INSTRUCTIONS TO ASSEMBLE

You should first mount one side of the engine guard then the other, otherwise the engine will be unsupported. All the screws replaced, should be tightened to the torque specified in the oem maintenance manual for your motorcycle. If no torque specifications are provided in the oem maintenance manual, may be used 54Nm for all M10 screws and 22Nm for the M8 screw.

Medium strength liquid thread-locker (i.e., "Loctite") should be used to secure all screws, bolts and nuts.

All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque.

ID.	DESCRIPTION	QTY.
1	Right up guard	1
2	Left up guard	1
3	M8x20 DIN912 screw	4
4	M8x40 DIN912 screw	2
5	M8 DIN985 locknut	2
6	M8 DIN125/A flat washer	6
7	Spile length 77	2
8	M8 DIN9021 flat washer	2
9	Connection rod	1
10	Plastic cap	2

FOR TO ASSEMBLE THE CRASH PADS, IF YOU ARE NOT A TRAINED MECHANIC, PLEASE CONTACT A SPECIALIST. MOTOPLASTIC, S.A. TAKES NO RESPONSIBILITY FOR DAMAGES CAUSED BY IMPROPER INSTALLATION. THE USE OF CRASH PADS DO NOT GUARANTEE A FULL PROTECTION IN CASE OF ACCIDENT. AFTER A FALL, EVALUATE THE DAMAGE TAKEN ON THE CRASH BARS. IN CASE OF DOUBT CHANGE THE DAMAGED SIDE. MOTOPLASTIC-PUIG DECLINE ANY RESPONSIBILITY IN CASE OF MOTORCYCLE DAMAGE.

MOUNTING INSTRUCTIONS

HIGH DEFENSE FOR
BMW R 1200 GS 2014

Ref.: 7542N

