

REF: 8514N

## MOUNTING INSTRUCTIONS

1) ve the slider (2) from the set supplied.

- Without removing the other slider (1), place the rod (3) through the axle from the left side. 2)
- 3) Mount the slider (2), fastening the set with the washer (5) and nut (4).

## Material supplied:

POSITION	DENOMINATION	AMOUNT
1	Left Slider	1
2	Right Slider	1
3	Rod	1
4	M6 nut DIN985	2
5	M6 washers DIN125	2
6	Stoppers with hoops of colors	8

