

## FRONT AXLE-SLIDER ADAPTABLE TO:

DUCATI MONSTER 696 08-11' DUCATI MONSTER 796 10-11' DUCATI MONSTER 1100/S/EVO

REF: 8515N

## MOUNTING INSTRUCTIONS

- 1) Remove the slider (1) from the set supplied.
- 2) Without removing the other slider (2), place the rod (3) through the axle from the right side.
- 3) Mount the slider (1), fastening the set with the washer (5) and nut (4).

## Material supplied:

ID.	DESCRIPTION	QTY.
1	Left Slider	1
2	Right Slider	1
3	Rod	1
4	M6 nut DIN985	2
5	M6 washers DIN125	2
6	Stoppers with hoops of colors	8

