

## INSTRUCTIONS TO ASSEMBLE

Remove the fasteners that subject the chassis to the engine, on the point marked below (and the opposite side). Mount the protectors on each own side as the figure below shows. Tighten the set, and place the caps.  
 All the screws replaced, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, may be used 54Nm for all M10 screws.  
 Medium strength liquid thread-locker (i.e., "Loctite") should be used to secure all screws, bolts and nuts.  
 All screws, bolts and nuts should be checked after driving the first 50km to ensure that all are retightened to the proper torque.

ID.	DESCRIPTION	QTY.
1	Plastic caps	2
2	M10/125x140 DIN912 screw	2
3	M10 DIN125/A washer	2
4	Nylon protector	2
5	Aluminium metal arrowhead	2

FOR TO ASSEMBLE THE CRASH PADS, IF YOU ARE NOT A TRAINED MECHANIC, PLEASE CONTACT A SPECIALIST.  
 MOTOPLASTIC, S.A. TAKES NO RESPONSIBILITY FOR DAMAGES CAUSED BY IMPROPER INSTALLATION.  
 THE USE OF CRASH PADS DO NOT GUARANTEE A FULL PROTECTION IN CASE OF ACCIDENT.  
 MOTOPLASTIC-PUIG DECLINE ANY RESPONSIBILITY IN CASE OF MOTORCYCLE DAMAGE.

## MOUNTING INSTRUCTIONS

### CRASH PADS FOR YAMAHA MT03 16'-

Ref.: 8589

